



NR.	QTY	DESCRIPTION	ARTICLE CODE
1	1	Base	XST-79800820
2	2	Helicoil	XST-FG101000
3	13	Washer	XST-FS100000
4	4	Hex Nut	XST-FM100000
5	4	Adjustment bolt M10 L=70	XST-79800280
6	1	Clamping Block	XST-79800260
7	2	Hex Bolt	XST-79800250
8	1	Vizierpunt C	XST-79800430
9	1	Clamp	XST-79800420
10	1	Wing knob	XST-F4001300
11	1	Column Stop	XST-79800270
15	1	Column	XST-79800310
16	1	Depth Indicator	XST-79220900
17	1	Angle Indicator	XST-79221000
18	1	Cylinder Head Cap Screw	XST-FBC05000
19	6	Washer	XST-FS10K100
20	2	Stabilisation Bar	XST-79800390
21	4	Hex-Head Bolt	XST-FB102500
22	2	Clamping Block	XST-79800400
23	1	Slitch Clamp	XST-79800870
24	1	Bolt M10	XST-79800410
25	1	Grip	XST-7980086A
26	1	Hexagon Socket Button Head Screw	XST-FBE12400
27	1	Endplate Column	XST-79800350
28	2	Countersunk Flat Head Self-tapping Screw	XST-FF363000
29	4	Pressure-ring	XST-F4261100
30	1	Slide House	XST-79800840
31	4	Slide Block	XST-79230100
32	1	Sliderblock Holder	XST-79800230
33	1	Adjusting Nut (Assembly)	XST-79800090
34	2	Bearing	XST-ET019A00
35	2	Shimring	XST-FS20P300
36	2	Spring Retaining Ring	XST-FR020000
37	1	Spindle	XST-79800380
39	1	Helicoil	XST-FG121800
40	1	Clamping Bolt	XST-79800540
41	1	Spirit Level (Rectangle)	XST-A5026000
42	1	Spirit Level (Round)	XST-F1066000
43	2	Cylinder Head Cap Screw	XST-FBC82500
44	2	Cylinder Head Cap Screw	XST-FBC01200
47	1	Motor Connection 3/8" (Ass)	XST-7B05B100

NR.	QTY.	DESCRIPTION	ARTICLE CODE
48	1	Base	XST-FBE12200
49	2	Helicoil	XST-FG102000
50	13	Washer	XST-7980201CA
51	4	Hex Nut	XST-N1402810
52	4	Adjustment bolt M10 L=70	XST-N1402900
53	1	Clamping Block	XST-79800710
54	2	Hex Bolt	XST-F0031000
55	1	Vizierpunt C	XST-FB108000